Pleasant Hearth

Warming Your Home. Warming Your Heart.

4 FT HEAVY-DUTY LOG RACK

MODEL #LS932-48



ATTACH YOUR RECEIPT HERE

Serial Number _____ Purchase Date _____

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-877-447-4768, 8:30 a.m. – 4:30 p.m., CST, Monday – Friday.

PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Vertical End	2
B	Horizontal Base Bar	2
C	Spreader Bar	2

HARDWARE CONTENTS (shown actual size)



AA	BB	CC	DD	EE
M8 x 75 Bolt Qty. 8	Nut Qty. 8	Washer Qty. 8	Wrench Qty. 1	Allen Wrench Qty. 1

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

WARNING

- Do not allow children to play with or around log rack.

CAUTION

- Place rack on hard, dry surface.
- Protect rack from moisture.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 15 minutes

Tools Required for Assembly (included): Wrench, Allen wrench.

ASSEMBLY INSTRUCTIONS

1. Attach the horizontal base bars (B) to one vertical end (A) by inserting two M8 x 75 bolts (AA) through predrilled holes in vertical end, spreader bar (C), and one end of each horizontal base bar (B). Secure with washer (CC) and nut (BB), then tighten with wrench (DD) and Allen wrench (EE).
   Repeat using second vertical end (A) and spreader bar (C).



Hardware Used

AA	M8 x 75 Bolt		x 8
BB	Nut		x8
CC	Washer		x8
DD	Wrench		x 1
EE	Allen Wrench		x 1

CARE AND MAINTENANCE

- Keep log rack protected from elements.
- Do not attempt to overload rack.
- Clean with mild detergent as needed.

WARRANTY

If within one year from the date of original purchase, this item fails due to a defect in material or workmanship, we will replace or repair at our option, free of charge. To order parts or to obtain warranty service, call 1-877-447-4768, 8:30 a.m. – 4:30 p.m., CST, Monday - Friday. This warranty does not cover defects resulting from improper or abnormal use, misuse, accident, or alteration. Failure to follow all instructions in the owner's manual will also void this warranty. The manufacturer will not be liable for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion of incidental or consequential damages may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-877-447-4768, 8:30 a.m. – 4:30 p.m., CST, Monday – Friday.

PART	DESCRIPTION	PART NO.
A	Vertical End	40-08-180
B	Horizontal Base Bar	40-08-181
C	Spreader Bar	40-08-182
AA	M8x75 Bolt	40-09-898
BB	Nut	40-09-899
CC	Washer	40-09-900
DD	Wrench	40-08-149
EE	Allen Wrench	40-08-150





40-10-127

Printed in China